


















Edana Maxi 328x180x1205

1. 328x180
2. 1148x326
3. 1148x30x30
4. 1148x30x30
5. 1148x143x4
6. 1148x143x4
7. 328x180
8. 1138x259x4
9. 297x130x4
10. 297x130x4
11. 297x130x4
12. 297x130x4
13. 297x130x4
14. 297x130x4
15. 297x130x4
16. 297x130x4



 B x4	 C x4	 D x4	 E x1	 F x1	 G x32	 H x4
 I x4	 J x2	 K x6	 L x2	 M x2	 N x1	 O x4



Upozornění:

Z bezpečnostních důvodů musí být nábytková část připevněna ke zdi příloženým upevňovacím materiálem který je vhodný pouze pro pevné stěny. Pro jiné stěny musí být použity speciální hmoždinky.

